

SMART DOORLOCK

OOBDLS1

OOB[®]
SMARTHOME
Touch The Future TODAY



www.oobsmarhome.com

UNIQUE FEATURES

⚙️ FAST FINGERPRINT SENSOR

50 fingerprints can be registered in this lock and unlocking speed is 0.5 seconds only.

⚙️ RFID CARD

300 RFID card can be registered in this lock, the RFID card is specially designed for this lock only for your security.

⚙️ PIN OPTION WITH VERY FINE TOUCH KEY PAD

You can register 100 pins in this lock and the Touch Key Pad is very fine to Use.

⚙️ LOW BATTERY INDICATION

The lock will give you an indication on the screen that the battery is low.

⚙️ RECORD HISTORY

You can Check Past Unlocking Records.

⚙️ EMERGENCY POWER

In case the battery is completely discharged, an external 5V Micro USB type cable can be used to give power to the lock.

⚙️ AUTO LOCKING SYSTEM

The lock will eliminate the manual locking as it will get locked automatically when the door gets closed.



PRODUCT PARAMETER

Power Supply : **4.5V-6V (4 pcs AA Cell power)**

Unlock Methods : **Fingerprint / RFID card
Passcode / Mechanical Key**

Quiescent Current : **<50-65uA**

Passcode Length : **6-8 Bits**

Card Volume : **100 pcs**

Password Volume : **100 pcs**

Finger Volume : **50 pcs**

Administrator : **9**

Lower Voltage Alarm : **4.5+0.2V**

Operating Temperature : **-10 C~60 C**

Door Thickness : **38-120mm**

Material : **Aluminium Alloy**

Size : **358*70MM**




USER MANAGEMENT

1. Initialization

Press the set button (rear panel button) for 5seconds. Voice will remind Initialization successfully.

Note: Initialization password is: 123456, or any fingerprint can unlock the lock.



Long press the back lock setting key, the countdown is over in 5 seconds, release and restore the factory setting successfully

2. Add administrator information (Up to three administrator users)


In the initialization state to wake up the screen press "*" #"

When add successfull, voice prompt "add administrator successfully" (can continuously add 9 times)


Voice prompt "Please add administrator information" (administrator can be fingerprint password or ID card)

USER MANAGEMENT


3. Add General User Information



4. Delete unlock information




5. Normally unlock mode



Note: After the normally open mode is turned on, every unlocking is normally open mode, and the lock will not be automatically closed, so it is necessary to manually unlock the lock once.

Semi installation diagram



1. front panel
2. connecting pipe
3. silicone pad
4. Fangxin
5. lock cylinder
6. lock body
7. Rear panel
8. Indoor locking knob
9. battery cover
10. Screw-fitting.

Note: When installing semi-automatic lock, adjust the clutch and direction of handle according to the direction of door opening.



OOBDLS1



OOBDLRxTx

For VDP - RF Chip Tx Rx Pair




OOBDLWF

For Application - WI-FI Chip

Exterior


Interior



DRILLING TEMPLATE



MORTISE HOLE



DOOR HOLE


DOOR THICKNESS



Suitable Door Thickness

Minimum - 35mm

Maximum - 65mm



www.oobsmarthome.com

OOB SMARTHOME INDIA PVT. LTD.

B-407,408,409, Shantiniketan Business Center,
Nr. Domino's Pizza, Gangotri Circle, Nikol
Ahmedabad - 382350, Gujarat, INDIA.

M :+91 90 81 87 87 89 | E : reach@oobsmarthome.com

Available On



Follow Us



Recognized & Trusted By

